Spare Part Book

ECO 7

GEO _macchine _agricole

Table of Contents

Tavola	Page
ECO7_parte 1	3
MOTORE JF340-390-420	7

GEO_macchine_agricole


60
59
37
40
39
65
64
45
44
46
42
38
41
36
48
49
50
47
34
33
35
57
29
63
55
51
52
56
32
31
30
28
27
14
15
16
21
22
62
13
12
17
18
19
20
26
23
11
61
8
10
9
7
6
25
24
5
3
4
2
53
54
1

Pos	Code	Description	NOTE	Q.
1	ECO7.100.01	rubber foot		2
2	ECO7.100.02	front foot		1
3	GB.ECO7.01	flat washer		0
4	GB.ECO7.02	hex nut		0
5	GB.ECO7.03	lock washer		0
6	GB.ECO7.04	hex bol t		1
7	ECO7.100.03	discharge chuter		1
8	ECO7.100.04	movable door		1
9	GB.ECO7.05	tube		3
10	ECO7.100.05	screen		1
10	ECO7.101.05.1	screen with small holes		1
11	GB.ECO7.06	pin		2
12	GB.ECO7.07	hitch pin		2
13	GB.ECO7.08	door axle		4
14	GB.ECO7.09	spacer I		4
15	GB.ECO7.10	spacer II		4
16	GB.ECO7.11	spacer III		8
17	ECO7.100.06	hammer		16
18	GB.ECO7.12	spacer IV		4
19	GB.ECO7.13	roll pin		4
20	GB.ECO7.14	hammer axle		4
21	ECO7.100.07	blade		1
22	GB.ECO7.15	flat HD SCREW (8X25)		1
23	ECO7.100.08	box frame side left		2
24	ECO7.100.09	wheel		1

Pos	Code	Description	NOTE	Q.
25	ECO7.100.10	wheel support		1
26	ECO7.100.11	blade cover pla te		1
27	GB.ECO7.16	wire circlip		1
28	GB.ECO7.17	washer(right)		1
29	GB.ECO7.18	chipping chute		2
30	GB.ECO7.19	bearing seat		2
31	GB.ECO7.20	ball bearing (UC205)		2
32	GB.ECO7.21	spacer (right)		1
33	ECO7.100.12	impeller		1
34	GB.ECO7.22	key		1
35	ECO7.100.13	rear board		1
36	ECO7.100.14	engine seat		1
37	ECO7.100.15	Engine		1
38	ECO7.100.16	rubber gasket		1
39	ECO7.100.17	hopper		1
40	ECO7.100.18	handles		2
41	GB.ECO7.23	hook		2
42	GB.ECO7.24	hex bolt		0
44	ECO7.100.20	Pulley + clutch		1
44	ECO7.100.20.2	Only clutch		1
45	ECO7.100.21	V-belt B1092		1
46	ECO7.100.22	pulley cover		1
47	GB.ECO7.25	belt cover bracket		1
48	GB.ECO7.26	spacer		1
49	ECO7.100.23	pulley		1

Pos	Code	Description	NOTE	Q.
50	GB.ECO7.27	special washer (left)		1
51	GB.ECO7.28	washer (right)		1
52	ECO7.100.24	box frame side		1
53	ECO7.100.25	wheel tube		2
54	ECO7.100.26	wheel axel		1
55	ECO7.100.27	front handle		2
56	ECO7.100.28	handle part		2
57	ECO7.100.29	box holder		2
59	ECO7.100.30	hitch trailer		1
60	GB.ECO7.29	hitch pin		2
61	GB.ECO7.30	bolt		0
62	GB.ECO7.31	bolt		0
63	6MQ-9	Battery 6MQ-9 - ECO7		1
64	ECO7.01.127	Engine_bolt M8x40		1
65	ECO.00.01	KIT Protezione Cuffie		1

GEO_macchine_agricole

OTORE JF340-390-42

GEO _ macchine _ agricole


Air cleaner
14
15
1
13
2
1
3
4
5
6
7
8
9
10
11
12

Pos	Code	Description	NOTE	Q.
1	JF340-O-01	AIR CLEANER COVER NUT		2
2	JF340-O-02	AIR CLEANER COVER		1
3	JF340-O-03	AIR CLEANER GROMMER		1
4	JF340-O-04	AIR CLEANER ELEMENT		1
5	JF340-O-05	OUTER FILTER		1
6	JF340-O-06	SILENCER NOSE		1
7	JF340-O-07	ELBOW PACKING		1
8	JF340-O-08	FLANGE BOLT (M6×20)		1
9	JF340-O-09	AIR CLEANER COLLAR		1
10	JF340-O-10	AIR CLEANER ELBOW COMP.		1
11	JF340-O-11	AIR CLEANER COLLAR		1
12	JF340-O-12	FLANGE NUT (M8)		2
13	JF340-O-13	AIR CLEANER ASSY.		1
14	JF340-O-14	COMPLETE AIR FILTER		1

GEO_macchine_agricole

Fan cover system assy.



Pos	Code	Description	NOTE	Q.
1	JF340-H-01	SHROUD		1
2	JF340-H-02	FLANGE BOLT (M6×14)		6
3	JF340-H-03	FAN COVER COMP.		1
4	JF340-H-04	CORD CLAMPER		1
5	JF340-H-05	ENGINE STOP SWITCH ASSY.		1

GEO _macchine_agricole

Flywheel system Assy.



Pos	Code	Description	NOTE	Q.
1	JF340-J-01A	FLYWHEEL		1
2	JF340-J-01B	FLYWHEEL		1
3	JF340-J-02	SPECIAL WOODRUFF KEY		1
4	JF340-J-03	COOLING FAN		1
5	JF340-J-04	STARTER PULLEY		1
6	JF340-J-05	FLYWHEEL NUT (M16)		1

GEO _macchine_agricole

Fuel tank system assy. 16



GEO_macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF340-P-01	FUEL TANK ASSY.		1
2	JF340-P-02	FLANGE BOLT (M8×25)		2
3	JF340-P-03	SUPPORTER RUBBER		1
4	JF340-P-04	TUBE CLIP		2
5	JF340-P-05	FUEL TUBE		1
6	JF340-P-06	O-RING (14mm)		1
7	JF340-P-07	FUEL TANK JOINT		1
8	JF340-P-08	FLANGE NUT (M6)		1
9	JF340-P-09	FUEL FILTER		1
10	JF168-N-11	FUEL FILLER CAP PACKING		1
11	JF340-P-10	FUEL FILLER CAP COMP.		1

GEO_macchine_agricole

Ignition System Assy. 11



GEO _macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF340-K-01	PLENUM CAP		1
3	JF340-K-03	STOP SWITCH CORD		1
4	JF340-K-04	STOP SWITCH CORD HOLDER		1
5	JF340-K-05	FLANGE BOLT (M6×25)		2
6	JF340-K-06	CORD GROMMENT		1
7	JF340-K-07	CHARGE COIL ASSY.		1
8	JF340-K-08	FLANGE BOLT (M6×40)		2
9	JF340-K-09	CORD CLAMPER		1
10	JF340-K-10	FLANGE BOLT (M6×20)		1

GEO _macchine_agricole

Muffler System Assy. 14



Pos	Code	Description	NOTE	Q.
1	JF340-N-01	TAPPING SCREW (M5×8)		4
2	JF340-N-02	MUFFLER PROTECTOR COMP.		1
3	JF340-N-03	MUFFLER COMP.		1
4	JF340-N-04	SPARK ARRESTER (SILENT)		1
5	JF340-N-05	EX. PIPE GASKET		1
6	JF340-N-06	EX. PIPE COMP.		1
7	JF340-N-07	MUFFLER GASKET		1
8	JF340-N-08	FLANGE NUT (M8)		2
9	JF240-N-09	MUFFLER ASSY.		1

GEO _macchine_agricole

Piston and connecting rod system assy. 5



Pos	Code	Description	NOTE	Q.
1	JF340-E-01	COMPRESSION RING A		1
2	JF340-E-02	COMPRESSION RING B		1
3	JF340-E-03	OIL RING A		2
4	JF340-E-04	OIL RING B		1
5	JF240-E-05	PISTON PIN CLIP (20 mm)		2
6	JF340-E-05	PISTON		1
7	JF340-E-06	PISTON PIN		1
8	JF340-E-07	CONNECTING ROD		1
9	JF340-E-08	CONNECTING COVER		1
10	JF340-E-09	CONNECTING ROD BOLT		2
11	JF340-E-10	PISTON RING SET		1

GEO_macchine_agricole

Recoil starter system assy. 7



Pos	Code	Description	NOTE	Q.
1	JF340-G-01	RECOIL STARTER ASSY.		1
2	JF340-G-02	CENTER SCREW		1
3	JF340-G-03	SPRING RETAINER		1
4	JF340-G-04	FRICTION SPRING		1
5	JF340-G-05	STARTER RATCHET		2
6	JF340-G-06	RATCHET SPRING		2
7	JF340-G-07	RECOIL STARTER REEL		1
8	JF340-G-08	START RETURN SPRING		1
9	JF340-G-09	RECOIL STARTER CASE COMP.		1
10	JF340-G-10	RECOIL STARTER ROPE		1
11	JF340-G-11	STARTER GRIP		1
12	JF340-G-12	FLANGE BOLT (M6×8)		3

GEO_macchine_agricole

Starter motor System assy. 12



Pos	Code	Description	NOTE	Q.
1	JF340-L-01	UNIT STARTER MOTOR		1
2	JF340-L-02	CONTACTOR ASSY.		1
3	JF340-L-03	FLANGE BOLT (M8×35)		2

GEO _macchine_agricole

Camshaft system assy. 6



Pos	Code	Description	NOTE	Q.
1	JF340-F-01	LOCKNUT		2
2	JF340-F-02	ADJUSTING NUT		2
3	JF340-F-03	ROCKER ARM		2
4	JF340-F-04	ROCKER BOLT (8 mm)		2
5	JF340-F-05	PUSH ROD GUIDE PLATE		1
6	JF240-F-06	ROD PUSH		2
7	JF240-F-07	CAM FOLLOWER		2
8	JF270-F-08	CAMSHAFT		1
9	JF340-F-06	EX. VALVE HELMET		1
10	JF340-F-07	EX. VALVE SPRING RETAINER		1
11	JF340-F-08	VALVE SPRING		2
12	JF340-F-09	VALVE SPRING SEAT		2
13	JF340-F-10	IN. VALVE SPRING RETAINER		1
14	JF340-F-11	EX. VALVE		1
15	JF340-F-12	IN. VALVE		1
16	JF340-F-13	ROCKER ASSY.		1

GEO_macchine_agricole

Carburetor system assy. 9



GEO _macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF340-I-01	INTAKE PIPE GASKET		1
2	JF340-I-02	CARBURETOR INSULATING PLATE		1
3	JF340-I-03	CARBURETOR PAPER GASKET		1
4	JF340-I-04A	CARBURETOR ASSY.		1
5	JF340-I-05	CARBURETOR IRON GASKET		1

GEO _macchine_agricole

Control box assy. 17



GEO _macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF390-Q-01	CONTROL BOX ASSY.		1

GEO _macchine_agricole

Control System Assy. 13



GEO _macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF340-M-01A	CONTROL ASSY.		1
2	JF340-M-02A	CONTROL BASE COMP.		1
3	JF340-M-03	CONTROL ADJUSTING SPRING		1
4	JF340-M-04	CROSS POND SCREW (M5×34)		1
5	JF340-M-05	FLANGE BOLT (M6×14)		1
6	JF340-M-06	GOVERNOR SPRING		1
7	JF340-M-07	THROTTLE RETURN SPRING		1
8	JF340-M-08	GOVERNOR ROD		1
9	JF340-M-09	FLANGE NUT (M6)		1
10	JF340-M-10	GOVERNOR ARM BOLT (M6)		1
11	JF340-M-11	CONTROL ARM		1

GEO_macchine_agricole

Crankcase cover system assy. 3



Pos	Code	Description	NOTE	Q.
1	JF340-B-11	OIL SEAL (diam 35× diam 52×8)		1
2	JF340-C-01	FLANGE BOLT (M8×35)		7
3	JF340-C-02A	OIL SCALE		2
4	JF340-C-03	OIL SCALE SEAL RING		2
5	JF340-C-04A	CRANKCASE COVER		1
6	JF340-B-04	BALL BEARING (6207)		1
7	JF340-B-13	BALL BEARING (6202)		1
8	JF340-C-05	SLIDER SHAFT		1
9	JF340-C-06	GOVERNOR GEAR WASHER (6 mm)		1
10	JF340-C-07	GOVERNOR GEAR		1
11	JF340-C-08	SLIDER WASHER (6 mm)		1
12	JF340-C-09	GOVERNOR SLIDER		1
13	JF340-C-10	CRANKCASE COVER PAD		1
14	JF240-C-11	DOWEL PIN (8×12)		2

GEO_macchine_agricole

Crankshaft system assy. 4



GEO _macchine_agricole

Pos	Code	Description	NOTE	Q.
1	JF340-D-01	CRANK		1
2	JF340-D-02	CRANKSHAFT COMP.		1
3	JF340-D-03	BALANCE SHAFT		1

GEO _macchine_agricole

Cylinder barrel

2



I

Pos	Code	Description	NOTE	Q.
1	JF340-B-01	FLANGE BOLT (M6×14)		3
2	JF240-B-02	OIL LEVEL SWITCH ASSY.		1
3	JF240-B-03	O-RING (14mm)		1
4	JF340-B-02	FLANGE NUT (10 mm)		1
5	JF340-B-03	CRANK CASE		1
6	JF340-B-04	BALL BEARING (6207)		1
7	JF340-B-05	WASHER (diam 8.3× diam 17×1)		1
8	JF340-B-06	LOCK PIN (10 mm)		1
9	JF340-B-07	GOVERNOR ARM SHAFT		1
10	JF340-B-08	OIL SEAL (diam 8× diam 14×5)		1
11	JF340-B-09	DRAIN PLUG WASHER (12 mm)		2
12	JF340-B-10	DRAIN PLUG BOLT		2
13	JF340-B-11	OIL SEAL (diam 35× diam 52×8)		1
14	JF340-B-12	OIL PROTECTOR		1
15	JF340-B-13	BALL BEARING (6202)		1

GEO_macchine_agricole

Cylinder head system assy. 1



Pos	Code	Description	NOTE	Q.
1	JF340-A-01	HEAD COVER COMP. BOLT		1
2	JF340-A-02	HEAD COVER WASHER COMP.		1
3	JF340-A-03	WASHER COVER PACKING		1
4	JF340-A-04	HEAD COVER COMP.		1
5	JF340-A-05	HEAD COVER PACKING		1
6	JF340-A-06	FLANGE BOLT (M10×80)		4
7	JF340-A-07	SPARK PLUG		1
8	JF340-A-08A	EXHAUST PIPE STUD BOLT		2
9	JF340-A-09	CYLINDER HEAD COMP.		1
10	JF340-A-10A	CARBURETOR STUD BOLT		2
11	JF340-A-11	CYLINDER HEAD SEALING PAD		1
12	JF340-A-12	DOWE L PIN (diam 10× diam 12×20)		2
13	JF340-A-13A	BREATHER TUBE		1

GEO_macchine_agricole