



Macchina


ECO7



Sezione

1

ECO7



SerNo	PartNo	Description	Quantity
1	ECO7.100.01	rubber foot	2
2	ECO7.100.02	front foot	1
3	GB.ECO7.01	flat washer	
4	GB.ECO7.02	hex nut	
5	GB.ECO7.03	lock washer	
6	GB.ECO7.04	hex bol t	1
7	ECO7.100.03	discharge chuter	1
8	ECO7.100.04	movable door	1
9	GB.ECO7.05	tube	3

10	ECO7.100.05	screen	1
11	GB.ECO7.06	pin	2
12	GB.ECO7.07	hitch pin	2
13	GB.ECO7.08	door axle	4
14	GB.ECO7.09	spacer I	4
15	GB.ECO7.10	spacer II	4
16	GB.ECO7.11	spacer III	16
17	ECO7.100.06	hammer	16
18	GB.ECO7.12	spacer YI	4
19	GB.ECO7.13	roll pin	4
20	GB.ECO7.14	hammer axle	1
21	ECO7.100.07	blade	1
22	GB.ECO7.15	flat HD SCR	1
23	ECO7.100.08	box frame side left	2
24	ECO7.100.09	wheel	1
25	ECO7.100.10	wheel support	1
26	ECO7.100.11	blade cover plate	1
27	GB.ECO7.16	wire circlip	1
28	GB.ECO7.17	washer(right)	1
29	GB.ECO7.18	chipping chute	2
30	GB.ECO7.19	bearing seat	2
31	GB.ECO7.20	ball bearing	2
32	GB.ECO7.21	spacer (right)	1
33	ECO7.100.12	impeller	1
34	GB.ECO7.22	key	1
35	ECO7.100.13	rear board	1
36	ECO7.100.14	engine seat	1
37	ECO7.100.15	tool box	1
38	ECO7.100.16	rubber gasket	1
39	ECO7.100.17	hopper	1
40	ECO7.100.18	handles	2
41	GB.ECO7.23	hook	2
42	GB.ECO7.24	hex bolt	
43	ECO7.100.19	burn-proof net	1
44,1	ECO7.100.20	Pulley + clutch	1
44,2	ECO7.100.20.2	Only clutch	1
45	ECO7.100.21	V-belt	1
46	ECO7.100.22	pulley cover	1
47	GB.ECO7.25	belt cover bracket	1

48	GB.ECO7.26	spacer	1
49	ECO7.100.23	pulley	1
50	GB.ECO7.27	special washer (left)	1
51	GB.ECO7.28	washer (right)	1
52	ECO7.100.24	box frame side	1
53	ECO7.100.25	wheel tube	2
54	ECO7.100.26	wheel axel	1
55	ECO7.100.27	front handle	2
56	ECO7.100.28	handle part	2
57	ECO7.100.29	box holder	2
59	ECO7.100.30	hitch trailer	1
60	GB.ECO7.29	hitch pin	2
61	GB.ECO7.30	bolt	
62	GB.ECO7.31	bolt	