



ECO 21 2014 2017




GEO Italy S.R.L.



Pos	Code	Description	NOTE	Q.
1	ECO21.2.001	Infeed Chute Weldment		1
2	ECO21.2.002	Reversing Lever		1
3	GB/T.889.1-2000-10	Lock Nut M10		3
4	GB/T97.1-2002-10	Plain washer 10		10
5	ECO21.1.005	BOLT M10×40		3
6	F-TH/DH-U01	Reversing Valve Unit for BX		1
7	ECO21.2.007	Permanents Flow Valves		1
8	GB/T.93-1987-10	Spring washer 10		4
9	ECO22.1.009	BOLT M12×50		6
10	ECO22.1.010	Roller Cover		1
11	ECO22.1.011	KEYS 8×40		1
12	F-TY-A02.P01	Hydraulic motor		1
13	ECO21.2.013	LOCKNUT 12		6
14	GB/T.95-2000-12	WASHER 12		12
15	ECO21.1.015	Bearings P208		2
16	F-TH06-2	FIXED FEEDING ROLLER		1
17	GB/T5783-M10x30	Bolt M10x30		1



Pos	Code	Description	NOTE	Q.
1	BX42-A01.W01	Chipper Disk Weldment		1
2	ECO21.10.02	BLADE 9		4
3	GB/T68-2000-M10x40	SCREW M10x40		16
4	GB/T.71-2000-16x50	Screws socket head M16x50		4
5	FTH21.3.005	POWER-INPUT-SHAFT		1
6	GB/T.889.1-2000-16	Lock Nut M16		4
7	GB/T.95-2000-16	WASHER 16		4
8	GB/T.889.1-2000-10	Lock Nut M10		16
9	GB/T97.1-2002-10	Plain washer 10		16



Pos	Code	Description	NOTE	Q.
1	BX62H-W01	Engine Body		1
3	BX62-W02	Upper Housing		1
4	ECO21.1.004	BEARING CAGE		1
5	GB/T.889.1-2000-6	Lock Nut M6		9
6	GB/T.95-2000-6	WASHER 6		9
7	ECO21.1.007	Turnplate Handle		1
8	ECO21.1.008	Turnplate Pin		1
9	ECO21.1.009	Platen Spring		1
10	GB/T5781-2000-M6×20	BOLT M6×20		7
11	BX62-W04	DISCHARGE TUBE		1
12	ECO21.1.012	Protective Cover Weldment		1
13	FRD-TY19	Support Pole		1
14	GB/T97.1-2002-8	Plain washer 8		10
15	GB/T.5780-2000-M8×140	BOLT M8×140		1
16	GB/T.889.1-2000-10	Lock Nut M10		11
17	ECO21.1.017	Platen		1
18	GB/T5781-2000-M6×25	BOLT M6×25		2
19	ECO21.1.019	Insulate Plate		1
20	ECO21.1.020	Lower Turnplate		1
21	GB825-88-M10	Ring bolt M10×20		6
22	ECO21.1.022	Locking Pin 8×40		3
23	ECO21.1.023	Clevis		1
24	GB/T.5782-2000-M12×40	BOLT M12×40		3
25	GB/T.95-2000-12	WASHER 12		10
26	GB/T5780-2000-M16×180	Bolt M16×180		1

Pos	Code	Description	NOTE	Q.
27	GB/T.889.1-2000-16	Lock Nut M16		1
28	ECO21.1.028	Left Bearing Cover		1
29	ECO21.1.029	Right Bearing Cover		1
30	ECO21.1.030	BOLT M10×60		2
31	F-TH06-1	ACTIVE FEEDING ROLLER(H)		1
32	GB/T.93-1987-10	Spring washer 10		4
33	ECO21.1.033	Infeed Chute		1
34	ECO21.1.034	Swing Arm		1
35	GB/T97.1-2002-10	Plain washer 10		19
36	GB/T.93-1987-16	Spring washer 16		16
37	GB/T5782-2000-M10x50	BOLT M10×50		2
38	ECO21.1.038	LOCKNUT 12		2
39	F-TY18	TENSION SPRING		4
40	ECO21.1.040	BOLT M12×50		2
41	ECO21.1.041	BOLT M16×55		8
42	GB/T.41-2000-16	Nut M16		8
43	F-TY-A02.P01	Hydraulic motor		1
44	GB/T.6184-2000-8	LOCKNUT 8		5
45	ECO21.1.045	BEARING F210-CHANGE		4
46	ECO21.1.046	BOLT M16×40		8
47	GB/T.95-2000-16	WASHER 16		21
48	ECO21.1.048	ANVIL		1
49	ECO21.1.049	Cylinder		2
50	GB/T.5781-2000-M8×30	BOLT M8×30		4
51	GB/T.41-2000-12	Nut M12		3

Pos	Code	Description	NOTE	Q.
52	GB/T.93-1987-12	Spring washer 12		3
53	GB/T.41-2000-27	Nut M27		2
54	GB/T.93-1987-27	Spring washer 27		2
55	ECO21.1.055	Hanger Pin		2
56	ECO21.1.011	KIT Discharge ECO21		1
57	ECO21.1.010	Estensione ECO21		1