


ATV



GEO Italy S.R.L.

AT120/145. 001A




Machine: ATV

Assembly: ATV_2020_PARTE1



Pos	Code	Description	NOTE	Q.
2	AT145.002	TOW BAR,ASSEMBLY		1
4	AT120.004	jack		1
5	AT120.103	spring		2
6	04.00.1.2	Kit Piedino		1
7	04.00.1.4	Throttle cable		1
8	04.00.1.7	Control Switch		1
9	04.00.1.6	KEY Switch		1
10	04.00.1.8	Safety Switch Ass.		1




Machine: ATV

Assembly: ATV_2020_PARTE2



Pos	Code	Description	NOTE	Q.
1	AT120.015	pulled pipe weldment		1
2	AT120.014	link pipe		1
3	AT120.105	bush		2
4	AT120.016	link plate weldment		1
5	AT120.106	pin		1
6	RP 3.2	R-PIN 3.2		1
7	GB5782-M16x65	Bolt M16x65		2
8	GB889.1-M16	Locking nut M16		3
9	GB5782-M16x80	Bolt M16x80		1
10	AT120.108	rod		1
11	GB91-5x30	COTTER 5x30		2
12	GB97.1-18	Plain washer 18		2
13	AT120.017	adjuster		1
14	QT50	Trailer coupler 2"		1
15	GB5782-M12x65	Bolt M12x65		2
16	GB889.1-M12	Locking nut M12		2

AT120/145.003A




Pos	Code	Description	NOTE	Q.
1	AT120.018A	DECK,WELDMENT		1
1	AT145.018A	DECK,WELDMENT		1
4	AT120.021	Left Skid		1
5	AT120.022	Right Skid		1
7	EFG120.105.3	small belt pulley 120mm 3 grooves		1
8	REACH 04-35x60	LOCKING DEVICE 04-35x60		1
9	GBIT1154-B1050	V-BELT B1050		2
10	AT120.009A	BELT TENSIONING DEVICE,ASSEMBLY		1
10	AT145.009A	BELT TENSIONING DEVICE,ASSEMBLY		1
11	6-DZM-14	Battery 6-DZM-14		1
12	AT120.131	Isolation Plate		1
13	AT120.132	Battery Cover		1
14	AT120.124	CLOSE PLATE		1
15	GB5782-M10x120	half thread bolt		2
16	AT120.013	Side Guard		2
17	AT120.104	Plug		2
18	GB1152- M8x1	GREASE NIPPLE M8x1		1
19	AT120.111	Stick		1
19	AT145.111	SHAFT,FENDER		1
20	EFGC125.113	Fender		12
20	EFGC125.113	Fender		45
21	GB5783-M12x30	Bolt M12X30		19
22	GB93-12	spring washer 12		9
23	AT120.011A	LOWER BRACKET,WELDMENT		1
23	AT145.011A	LOWER BRACKET,WELDMENT		1

Machine: ATV

Assembly: ATV_2020_PARTE3



Pos	Code	Description	NOTE	Q.
24	AT120.101A	LOWER COVER		1
25	GB889.1-M12	Locking nut M12		10
26	GB91-3.2x16	cotter pin 3.2x16		2
27	GB97.1-10	PLAIN WASHER 10		3
28	GB97.1-8	Plain washer 8		4
29	GB889.1-M8	Locking nut M8		4
30	GB5783-M6x12	bolt M6X12		2
31	GB93-6	spring washer 6		2
32	GB97.1-6	Plain washer 6		2




Machine: ATV

Assembly: ATV_2020_PARTE4



Pos	Code	Description	NOTE	Q.
1	AT120.028	outside pipe		1
2	AT120.029	screw thread rod		1
3	AT120.030	inside pipe		1
4	GB301-51104	Bearing 51104-8104		1
5	GB276-600104	BEARING 600104		1
6	AT120.027	handle		1
7	GB70.1-M8x35	bolt M8X35		1
8	GB1152-M8x1	Grease Nipple M8x1		1
9	AT120.120	Handle Sleeve		1
10	GB5782-M12x65	Bolt M12x65		1
11	GB97.1-12	plain washer 12		1
12	GB889.1-M12	Locking nut M12		2
13	GB5783-M12x40	bolt M12x40		1




Machine: ATV

Assembly: ATV_2020_PARTE5



Pos	Code	Description	NOTE	Q.
1	AT120.031	linkage		2
2	AT120.032	wheel frame		1
2	AT145.032	WHEEL CARRIER?WELDMENT		1
3	AT120.005-A	TYRE ASSEMBLY		2
4	GB889.1-M20	Locking nut M20		2
5	GB5782-M10x110	Bolt M10x110		4
6	GB889.1-M10	Locking nut M10		6
7	GB5782-M10x70	Bolt M10x70		2

AT120/145.006



Machine: ATV

Assembly: ATV_2020_PARTE6




Pos	Code	Description	NOTE	Q.
1	AT120.026	Blade Axle		1
2	EFGC125.115	Flange Bearing UC 207		2
3	UC207	Bearing UC207		2
4	RK120.109.3	Spacer lower for Pulley 3 grooves		1
5	GB13871-55x80x8	Oil Seal 55x80x8		1
6	GB1152- M8x1	GREASE NIPPLE M8x1		1
7	ef.100.00.102	Blade Ø 12		56
8	ef.100.00.103	Spacer 12		56
9	GB5782-M12x80	Bolt M12x80		28
10	GB889.1-M12	Locking nut M12		28

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 16

AT120/145. 007




Machine: ATV

Assembly: ATV_2020_PARTE7



Pos	Code	Description	NOTE	Q.
1	AT120.025	Roller		1
1	AT145.025	ROLLER,WELDMENT		1
2	AT120.019	Left Support Plate		1
3	AT120.020	Right Support Plate		1
4	GB2673-M8x25	Bolt M8x25		8
5	EFGC125.107	Bearing seat UCF205		2
6	UC205	Bearing UC205		2
7	GB5783-M12x30	Bolt M12X30		4
8	GB889.1-M12	Locking nut M12		4
9	GB1152- M8x1	GREASE NIPPLE M8x1		2

AT120/145. 008




Machine: ATV

Assembly: ATV_2020_PARTE8



Pos	Code	Description	NOTE	Q.
	AT145.117	BLOCK		1
1	JF420E	ENGINE JF420E		1
2	GB1096-6.3x6.3x50	KEY B6.3x6.3x50		1
3	AT120.012	Upper Cover Base		1
3	AT145.012	TOP BRACKET,WELDMENT		1
4	L100B3.001	Pulley Clutch Assembly 3 Grooves		1
5	AT120.114.3	Spacer Washer for Pulley 3 grooves		1
6	GB93-12	spring washer 12		1
7	UNF 7-16-20x1.5	BOLT UNF7/16-20x1.5		1
7	UNF 7-16-20x2	BOLT UNF7/16-20x2		1
8	AT120.102-1	TOP COVER		1
8	AT145.102	TOP COVER		1
9	GB5782-M10x45	Bolt M10x45		4
10	GB97.1-10	PLAIN WASHER 10		4
11	GB889.1-M10	Locking nut M10		4
12	UNF 5-16-24x1	BOLT 5/16-24x1 UNF		4
13	GB93-8	Spring washer 8		8
14	GB97.1-8	Plain washer 8		8
15	GB5783-M8x20	bolt M8X20		4

AT120/145. 009A




Machine: ATV

Assembly: ATV_2020_PARTE9



Pos	Code	Description	NOTE	Q.
1	AT120.041	CONNECTING LINK,WELDMENT		1
2	AT120.140	SPRING		1
3	GB889.1-M12	Locking nut M12		1
4	GB.T96.2-12×3			1
5	AT120.024A	SWING ARM,WELDMENT		1
5	AT145.024A	SWING ARM,WELDMENT		1
6	GB893.1-47	Circlip 47		1
7	GB276-303	BEARING 303		2
8	AT120.115	Tensioner Pulley		1
8	AT145.115	TENSION PULLEY		1
9	GB96-8	Plain washer 8		1
10	GB93-8	Spring washer 8		1
11	GB5783-M8x20	bolt M8X20		1
12	AT120.123A	BUSHING		1
13	GB93-12	spring washer 12		1
14	GB.T6170-M12			1
15	AT120.141	PLATE		1
16	GB.T70.1-M6×12			2
17	AT120.142	COVER		1

AT120/145. 005-A




Machine: ATV

Assembly: ATV_2020_PARTE5-A1



Pos	Code	Description	NOTE	Q.
1	AT120.033	wheel axle		1
2	GB276-205	Bearing 205		2
3	16x6.5-8	ATV tire assembly		1
5	GB96-11x34x3	PLAIN WASHER 11x34x3		1
6	GB93-10	spring washer 10		1
7	GB5783-M10x25	Bolt M10X25		1
8	AT120.122	Dust Cover		1



Machine: ATV

Assembly: Optional



Pos	Code	Description	NOTE	Q.
1	AT120E.011			1
2	AT120E.012			1
3	AT120E.013	BOLT M12x70		1
4	AT120E.014	NUT M12		1
5	AT120E.015	BOLT M12X45		1
6	AT120E.016			1
7	AT120E.017			1
8	AT120E.018			1
9	AT120E.019			1