


ECO 17 2008 2009






Pos	Code	Description	NOTE	Q.
1	WCM8-00011	CHIPPER SEAT WELDMENT		0
2	WCL5-00101	PIN FOR UP-LINK		0
3	200.56.011	Lock pin		0
4	EF100.00.019	Support		0
5	FM120.00.401	PTO GUARD		0
6	WCM8-03011	PULLEY COVER		0
7	WCM8-00163	BAFFLE BOARD		0
8	WCM8-00017	BACK COVER		0
9	WCM8-02001	CHIPPER BODY WELDMENT		0
10	GB/T91	R pin		1
11	WCL5-00133	LOCKING PIN		0
12	GB6184-86/M10	Locking nut M10		0
13	GB97.1-85/10-30	PLAIN WASHER M10*30		0
14	GB70.3-2000/M10x30	BOLT M10*30		0
15	WCM8-02101	BED BLADE		0
16	WCM8-00188	COVER TAKE OUT PLATE		0
17	WCM8-00033	WINDOW COVER BOARD		0
18	WCL5-00105	RUBBER WASHER		0
19	WCM8-00104	COMPACT BOARD		0
20	GB97.1-85/16	Plain washer 16		0
21	GB6170-86-M16	Nut M16		0
22	WCM8-00015	DISCHARGE BUCKET		0
23	WCM8-00166	DOWN COVER BOARD		0
24	WCM8-00013	GEAR BOX COVER		0
25	WCL8-00110	PLASTIC BAFFLE BOARD		0

Machine: ECO 17 2008 2009


Assembly: ECO17oldoldold_parte 0



Pos	Code	Description	NOTE	Q.
26	WCL8-00111	COMPACT BOARD		0
27	24PMF.01.117	Connecting plate		0
28	WCM8-00117	RIGHT CHARGING BOARD		0
29	WCM8-00119	UPPER CHARGING BOARD		0
30	WCM8-00116	DOWN CHARGING BOARD		0
31	WCM8-00118	LEFT CHARGING BOARD		0




Pos	Code	Description	NOTE	Q.
1	WCM8-00015	DISCHARGE BUCKET		0
2	WCM8-00191	SPACER		0
3	GB5783-86/M10×35	Bolt M10x35		0
4	GB97.1-85/10	Plain washer 10		0
5	GB6184-86/M10	Locking nut M10		0
6	WCM8-00180	COMPACT BOARD		0
7	WCM8-00036	DISCHARGE PIPE WELDMENT		0
8	FM100.00.018	BOLT ASSEMBLY		0
9	WCM8-00012	DISCHARGE COVER		0
10	WCM8-00038	HANDLE ASSEMBLY		0
11	GB879-86/6x24	SPRING PIN 6*24		0
12	WCM8-00184	LOCK PIN		0
13	WCM8-00185	LOCK SUPPORTING		0
14	WCM8-00186	LOCK SUPPORTING SEAT		0




Pos	Code	Description	NOTE	Q.
1	GB5783-86/M10×30	Bolt M10x30		0
2	GB6170-86-M10	Nut M10		0
3	WCM8-00193	CONNECTING PLATE		0
4	WCM8-00023	STOP HANDLE		0
5	S26.01.103	Handle cover		0
6	WCM8-00027	ROLLER LIFT HANDLE		0
7	WCM8-00194	CONNECTING PLATE		0
8	WCM8-00022	LOCKING LINE		0
9	WCM8-00026	SWING BODY		0
10	GB5783-86/M12x30	Bolt M12x30		0
11	GB97.1-85/12	Plain washer 12		0
12	GB6184-86/M12	Locking nut M12		0
13	GB5783-86/M12x30	Bolt M12x30		0
14	GB93-87-6	Spring lock washer 6		0
15	GB97.1-85/6	Plain washer 6		0
16	WCM8-00032	LIFT SUPPORT SHAFT		0
17	GB6184-86/M10	Locking nut M10		0
18	GB97.1-85/10	Plain washer 10		0
19	GB5783-86/M10×25	Bolt M10x25		0
20	WCM8-00031	LIFT CONNECT SUPPORT FOR ROLLER		0
21	WCL8-00170	SPRING		0
22	WCM8-00131	ROLLER SHAFT		0
23	WCM8-00030	LIST ARM		0
24	UCFL204	BEARING SEAT UCFL204		1
25	WCM8-00028	ROLLER		0

Pos	Code	Description	NOTE	Q.
26	24PMF.03.017A	Outer drive shaft		0
27	WCL8-00170	SPRING		0
28	24PMF.03.018A	inner drive shaft		0
29	24PMF.03.108	Clutch outer claw		0
30	24PMF.03.107	Clutch inner claw		0
31	GB11544-97	BELT		0
32	24PMF.03.105	BELT PULLEY		0
33	WCM8-00187	REDUCE SUPPORT		0
34	GB5783-86/M8x20	Bolt M8x20		0
35	GB93-87-8	Spring lock washer 8		0
36	GB97.1-85/8	Plain washer 8		0
37	GB6184-86/M6	Locking nut M6		0
38	WCM8-00189	UNLOCK BOARD		0
39	GB5782-86/M6x30	Bolt M6x30		0
40	WCM8-00190	SPRING		0
41	Q/IAKY01-91	WORM REDUCTION GEAR		0
42	WCM8-00182	PULL BOARD		0
43	WCM8-00122	LOCKING BOARD		0
44	GB5783-86/M8x30	Bolt M8x30		0
45	GB6170-86-M8	Nut M8		0
46	WCM8-00121	SPRING		0
47	GB5782-86	BOLT		0
48	WCM8-00183	SUPPORT BOARD		0
49	GB6184-86/M8	Locking nut M8		0
50	WCM8-00181	LOCKING SEAT		0



Pos	Code	Description	NOTE	Q.
1	WCL5-00114	NUT M40*1.5		0
2	WCL5-00115	LOCKING WASHER		0
3	WCL8-00112	LARGE BELT PULLEY		0
4	GB11544-97	BELT		0
5	GB6184-86/M16x1.5	Locking nut M16X1.5		0
6	GB97.1-85/16	Plain washer 16		0
7	GB278-89-104	BEARING 104		0
8	WCL5-00107	SPACER		0
9	WCL5-00106	TENSION WHEEL		0
10	WCL5-00016	TENSION WHEEL SUPPORT		0
11	WCM8-00017	BACK COVER		0
12	GB6184-86/M30	Locking nut M30		0
13	WCL8-00108	SMALL BELT PULLEY		0
14	UCF207	BEARING SEAT UCF207 SQUARED		0
15	GB6184-86/M12	Locking nut M12		0
16	GB6184-86/M10	Locking nut M10		0
17	GB5287-85	BIG PLAIN WASHER		0
18	GB5783-86/M12x40	Bolt M12x40		0
19	GB/T.1096-2003-12x50	Flat key 12*50		0
20	WCL5-00109	OUTPUT SHAFT		0
21	UCFL207	BEARING SEAT UCFL207		0
22	GB6184-86/M14	Locking nut M14		0
23	GB5783-86/M14x45	Bolt M14X45		0
24	GB97.1-85/12	Plain washer 12		0
25	GB6170-86-M12	Nut M12		0

Pos	Code	Description	NOTE	Q.
27	GB/T.1096-2003-10x25	Flat key 10*25		0
28	WCL5-00018	SUPPORT BEARING SEAT		0
29	WCM8-02001	CHIPPER BODY WELDMENT		0
30	MZ105.115	Retaining Lock washer		0
31	GB93-87-12	Spring lock washer 12		0
32	GB5783-86/M12x30	Bolt M12x30		0
33	WCL8-00130	BELT PULLEY		0
34	GB/T.1096-2003-6x14	Flat key C6*14		0



Pos	Code	Description	NOTE	Q.
1	GB6170-86-M12	Nut M12		0
2	GB93-87-12	Spring lock washer 12		0
3	WCL8-01011	FLY WHEEL AXLE		0
4	GB5783-86/M10x40	Bolt M10X40		0
5	GB93-87	SPRINGWASHER		0
6	WCM8-01102	COMPACT BOARD FOR BLADE		0
7	WCM8-01101	BLADE		0
8	GB5783-86/M8x30	Bolt M8x30		0
9	GB6170-86-M8	Nut M8		0
10	WCM8-01010	FLY WHEEL ASSEMBLY		0
11	GB5783-86/M12x50	Bolt M12x50		0