


Assembly: J_parte 1



Machine: J

Assembly: J_parte 1




Pos	Code	Description	NOTE	Q.
1	MBP32501	U BOLT		6
2	MBP32502	NUT		14
3	MBP32503	FRAME		1
4	MBP32504	BOLT NUT AND WASHER		1
5	MBP32505	DRAWBAR		1
6	MBP32506	U BOLT		1
7	MBP32507	WHEEL ASSEMBLY		1
8	MBP32508	BOLT NUT AND WASHER		1
9	MBP32509	DRAWBAR		2
10	MBP32510	BOTTOM PLOUGH BODY		3
11	MBP32511	PLOUGH SHARE		3
12	MBP32512	BOLT NUT AND WASHER		9
13	MBP32513	BOLT NUT AND WASHER		14
14	MBP32514	BLADE		3
15	MBP32515	BOLT NUT AND WASHER		2
16	MBP32516	BOLT NUT AND WASHER		1
17	MBP32517	ADJUST PLATE		1
18	MBP32518	NUT- WASHER AND SPRING WASHER		1

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 4

Assembly: J_parte 2




Machine: J
Assembly: J_parte 2



Pos	Code	Description	NOTE	Q.
2	MBP32502	NUT		1
13	MBP32513	BOLT NUT AND WASHER		1
19	MBP32519	PIN		2
20	MBP32520	SIDE PLATE 1		2
21	MBP32521	SIDE PLATE 2		1
22	MBP32522	SIDE PLATE 2 (SKID)		1

Assembly: J_parte 3



Machine: J

Assembly: J_parte 3




Pos	Code	Description	NOTE	Q.
1	MBP42501	U BOLT		8
2	MBP42502	NUT		18
3	MBP42503	FRAME		1
4	MBP42504	BOLT NUT AND WASHER		1
5	MBP42505	DRAWBAR		1
6	MBP42506	U BOLT		1
7	MBP42507	WHEEL ASSEMBLY		1
8	MBP42508	BOLT NUT AND WASHER		1
9	MBP42509	DRAWBAR		2
10	MBP42510	BOTTOM PLOUGH BODY		4
11	MBP42511	PLOUGH SHARE		4
12	MBP42512	BOLT NUT AND WASHER		12
13	MBP42513	BOLT NUT AND WASHER		18
14	MBP42514	BLADE		4
15	MBP42515	BOLT NUT AND WASHER		2
16	MBP42516	BOLT NUT AND WASHER		1
17	MBP42517	ADJUST PLATE		1
18	MBP42518	NUT- WASHER AND SPRINGWASHER		1

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 8

Assembly: J_parte 4



Machine: J

Assembly: J_parte 4




Pos	Code	Description	NOTE	Q.
2	MBP32502	NUT		1
13	MBP32513	BOLT NUT AND WASHER		1
19	MBP42519	PIN		2
20	MBP42520	SIDE PLATE 1		3
21	MBP42521	SIDE PLATE 2		1
22	MBP42522	SIDE PLATE 2(SKID)		1

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 10



Machine: J

Assembly: J_parte 5



Pos	Code	Description	NOTE	Q.
1	MBP32507.1	WASHER		1
2	MBP32507.2	BOLT NUT AND WASHER		4
3	MBP32507.3	COVER PLATE		1
4	MBP32507.4	ADJUST POLE		1
5	MBP32507.5	HAIR PIN		1
6	MBP32507.6	SQUARE TUBE		1
7	MBP32507.7	BOLT		1
8	MBP32507.8	NUT		1
9	MBP32507.9	SQUARE SHAFT		1
10	MBP32507.10	RING PLATE		1
11	MBP32507.11	BUSH 1		1
12	MBP32507.12	SEALING RING		1
13	MBP32507.13	BEARING		2
14	MBP32507.14	WHEEL		1
15	MBP32507.15	BEARING BASE		1
16	MBP32507.16	BOLT NUT AND WASHER		6
17	MBP32507.17	OIL CUP		1
18	MBP32507.18	BUSH 2		1
19	MBP32507.19	WASHER		1
20	MBP32507.20	LOCK WASHER		1
21	MBP32507.21	NUT		1
22	MBP32507.22	GASKET		1
23	MBP32507.23	BEARING BASE COVER		1

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 12