

Macchina




AC



Sezione

1

AC



SerNo	PartNo	Description	Quantity
7	BC 230C-FF (AC5)	FRONT FRAME	1
7,1	BC 230C-FF (AC7)	FRONT FRAME	1
7,2	BC 230C-FF (AC9)	FRONT FRAME	1
8	BC 230C-FR (AC5)	REAR FRAME	1
8,1	BC 230C-FR (AC7)	REAR FRAME	1
8,2	BC 230C-FR (AC9)	REAR FRAME	1
9	BC 230-LF	3 POINT LINKAGE FRONT	1
10	BC 230-LR	3 POINT LINKAGE REAR	1
11	BC 230C-001 (AC5)	TYNE	5

11,1	BC 230C-001 (AC7)	TYNE	7
11,2	BC 230C-001 (AC9)	TYNE	9
12	BC 230C-002 (AC5)	SPRING	10
12,1	BC 230C-002 (AC7)	SPRING	14
12,2	BC 230C-002 (AC9)	SPRING	18
13	BC 230C-003 (AC5)	SHOVEL - TEETH	5
13,1	BC 230C-003 (AC7)	SHOVEL - TEETH	7
13,2	BC 230C-003 (AC9)	SHOVEL - TEETH	9
14	BC 230C-004	DOUBLE TILLER PIN	2
15	BC 230C-005 (AC5)	U BOLT	5
15,1	BC 230C-005 (AC7)	U BOLT	7
15,2	BC 230C-005 (AC9)	U BOLT	9
16	BC 230C-006	SPACER PIN WITH TURNING & GRO	
17	BC 230C-007	SPACER PIN WITH GROVE	
18	BC 230C-008	BOLT 5/8 X 2" H.T	4
19	BC 230C-009 (AC5)	BOLT 5/8 X 3.5" H.T	5
19,1	BC 230C-009 (AC7)	BOLT 5/8 X 3.5" H.T	7
19,2	BC 230C-009 (AC9)	BOLT 5/8 X 3.5" H.T	9
20	BC 230C-010	BOLT 5/8 X 4.5" H.T	1
21	BC 230C-011 (AC5)	NUT 5/8"	10
21,1	BC 230C-011 (AC7)	NUT 5/8"	12
21,2	BC 230C-011 (AC9)	NUT 5/8"	14
22	BC 230C-012 (AC5)	WASHER 5/8"	10
22,1	BC 230C-012 (AC7)	WASHER 5/8"	12
22,2	BC 230C-012 (AC9)	WASHER 5/8"	14
23	BC 230C-013 (AC5)	BOLT 1/2 X 1-1/4" FULL THREAD	20
23,1	BC 230C-013 (AC7)	BOLT 1/2 X 1-1/4" FULL THREAD	28
23,2	BC 230C-013 (AC9)	BOLT 1/2 X 1-1/4" FULL THREAD	36
24	BC 230C-014 (AC5)	NUT 1/2"	20
24,1	BC 230C-014 (AC7)	NUT 1/2"	28
24,2	BC 230C-014 (AC9)	NUT 1/2"	36
25	BC 230C-015 (AC5)	WASHER 1/2"	20
25,1	BC 230C-015 (AC7)	WASHER 1/2"	28
25,2	BC 230C-015 (AC9)	WASHER 1/2"	36
26	BC 230C-016 (AC5)	SHOVEL BOLT 3/8 X 2"	10
26,1	BC 230C-016 (AC7)	SHOVEL BOLT 3/8 X 2"	14
26,2	BC 230C-016 (AC9)	SHOVEL BOLT 3/8 X 2"	18
27	BC 230C-017 (AC5)	NUT 3/8"	10
27,1	BC 230C-017 (AC7)	NUT 3/8"	14

27,2	BC 230C-017 (AC9)	NUT 3/8"	18
28	BC 230C-018 (AC5)	FRONT TINE ASSEMBLY	2
28,1	BC 230C-018 (AC7)	FRONT TINE ASSEMBLY	3
28,2	BC 230C-018 (AC9)	FRONT TINE ASSEMBLY	4
29	BC 230C-019	LYNCH PIN (6MM , DIA 45)	2
30	BC 230C-020 (AC5)	REAR TINE ASSEMBLY	2
30,1	BC 230C-020 (AC7)	REAR TINE ASSEMBLY	3
30,2	BC 230C-020 (AC9)	REAR TINE ASSEMBLY	4
31	BC 230C-021 (AC5)	FRONT TINE FRAME LEFT	2
31,1	BC 230C-021 (AC7)	FRONT TINE FRAME LEFT	3
31,2	BC 230C-021 (AC9)	FRONT TINE FRAME LEFT	4
32	BC 230C-022 (AC5)	FRONT TINE FRAME RIGHT	2
32,1	BC 230C-022 (AC7)	FRONT TINE FRAME RIGHT	3
32,2	BC 230C-022 (AC9)	FRONT TINE FRAME RIGHT	4
33	BC 230C-023 (AC5)	REAR TINE FRAME LEFT	3
33,1	BC 230C-023 (AC7)	REAR TINE FRAME LEFT	4
33,2	BC 230C-023 (AC9)	REAR TINE FRAME LEFT	5
34	BC 230C-024 (AC5)	REAR TINE FRAME RIGHT	3
34,1	BC 230C-024 (AC7)	REAR TINE FRAME RIGHT	4
34,2	BC 230C-024 (AC9)	REAR TINE FRAME RIGHT	5