


ECO16 2010_2013



Assembly: ECO16_parte 1



Machine: ECO16 2010_2013

Assembly: ECO16_parte 1




Pos	Code	Description	NOTE	Q.
2	1011L127	Plate- Spacer Ring		2
3	1011L134	Plate- Hood Capture		1
4	1011L133	Deflector- Discharge Chute		1
5	1011L130	Plate- Hood Capture		1
6	1011W106	Discharge Chute		1
7	1012W208	Assembly- Hood Latch		1
8	GB/T5783/M6x20	Bolt M6x20		8
9	GB/T889.1/M6	Lock Nut M6		8
10	Z31403	Spring 25mm x 178mm Heavy		0
11	Z92304	Single-Jack Chain #10 (35 links)		1
12	Z19313	Knob		2
13	GB/T802/M8	Acorn Nut M8		2
20	1011L151	Safety Flap Bar		1
21	1011A102	Self-Feed Hopper		1
22	1012S203	Flap- Hopper		0
23	GB/T889.1/M8	Lock Nut M8		3
24	GB/T12/M8x25	Carriage Bolt M8x25		3

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 15

Assembly: ECO16_parte 2



Machine: ECO16 2010_2013

Assembly: ECO16_parte 2



Pos	Code	Description	NOTE	Q.
3	1011L106	Bracket- PTO Cover Mount		0
4	1011L112	PTO Cover		1
5	1011M103	Knife- Rotor		0
6	1011M104	Knife- Ledger		0
7	1011W101	Housing- Bottom Rotor		0
8	1011W102	Housing- Upper Rotor		0
9	1011W103	Rotor		1
10	1011W104	Twig Breaker		1
11	Z11431	Implement Pin		2
12	Z12110	Latch Pin		1
13	Z25204-F208	4-Bolt Bearing F208		2
14	GB/T1152-89/M6	Grease Zerk M6		2
15	Z44501	#5 PTO Shaft M10 Shear		1
16	GB/T5783/M6x20	Bolt M6x20		2
17	GB/T5783/M12x30	Bolt M12x30		7
18	GB/T5786/M8x1x1	Bolt M8x1x15		19
19	GB/T5786/M16x1.	Bolt M16x1.5x45		8
20	GB/T889.1/M6	Lock Nut M6		2
21	GB/T93/22	Lock Washer 22		2
22	GB/T889.1/M12	Lock Nut M12		5
23	GB/T6177.1/M10	Flange Nut M10		2
24	GB/T6171/22x1.5	Nut M22x1.5		2
25	GB/T97.1/8	Plain Washer 8		3

GEO Italy S.R.L.

Via G. Abbate, 215, 14054 Castagnole delle Lanze AT

Page 17